

## **MARKING INSTRUCTIONS** **FOR NZGL PLUGS**

All the size 1511, 1513 and 1515 NZGL plug flight connectors are required to have a 10-589625-( ) spacer kit installed in front of and utilizing the connector backshell. To identify those connectors as having the spacer kit installed the NZGL part number roll-over indicator is a "-1" (dash one) added at the end of the NZGL part number.

Connectors supplied by AAO with the spacer kit will have the "-1" electroetched after the NZGL part number and will not require additional marking.

All flight connectors supplied without the "-1" need the "-1" marking added at the time the kit is installed.

### **MARKING PROCEDURE**

Mask all unaffected areas to prevent entrapment of fluids or particles.

Mark the "-1" after the NZGL part number with a vibrating tool. A suitable chemical conversion protective coating shall be applied over the additional marking.

Example of new part number: NZGL06G1511N2PA-1

For more information contact:

Amphenol Corporation  
Amphenol Aerospace  
40-60 Delaware Ave.  
Sidney, New York 13838-1395  
Phone: 607-563-5011