

Contact, Pin, Coaxial Type JT-R, LJT-R, TV-R, Crimp (MIL-C-38999 Series I, II & III)
Installation Instructions


See table on reverse side for coaxial cable recommended, type assembly instructions code, stripping dimensions, tool selector settings, crimping tool, positioner and insertion/removal tool information.

Type
Assy. Figure

- I A Strip cable as illustrated. Ends must be cut cleanly and at right angles to the axial plane of the cable. The cable must not be deformed while making cuts. Hot wire stripping is recommended.
- II B 1. Slide shield crimp sleeve back over cable jacket.
2. Flare shield as illustrated and strip cable dielectric.
- III C Flare shield as illustrated and strip cable dielectric.
- II, III D/ E 1. Slide rear insulator over cable center conductor and under cable shield until dielectric bottoms against rear insulator recess.
2. Slide inner socket contact over cable center conductor. Cable center conductor must be visible through the inspection hole in the inner socket contact wire well.
3. Crimp inner socket contact wire well using crimp tool and positioner listed in table on back.
- III F 1. Comb shield forward over back insulator and inner socket contact and install shield crimp sleeve.
2. Flare shield in front of crimp sleeve as illustrated.
- II, III G Slide front insulator, large end first, over the inner socket contact until insulator seats against inner socket contact shoulder, if front insulator is not captivated inside the outer pin contact.
- II, III H Slide outer contact over inner socket assembly and under cable shield until inner socket contact and front insulator are fully seated.
- II, III J 1. Bring shield crimp sleeve forward over cable shield and observe .240 - .270 dimension. Trim excess shield ahead of shield crimp sleeve.
2. Crimp shield crimp sleeve using tool and positioner listed in table on back as follows: Crimp once, rotate the contact assembly 45° and crimp a second time. After crimping the second time, the diameter over the shield crimp sleeve must not be greater than .156.
- I **Contact Insertion**
Using insertion tool (see table on back), insert contact assembly into rear connector grommet hole. Contact must be aligned with hole and not inserted at an angle. Push forward until contact is felt to snap into position within insert. Remove tool.
- I **Contact Removal**
Position removal tool (see table on back), around cable and slide tool down wire until tool tips enter rear grommet and come to a positive stop. Hold tool tip firmly against positive stop on contact, grip wire and simultaneously remove tool, contact and cable.

L-2035-C
August 2001

FSCM 77820



Amphenol Aerospace

AMPHENOL CORPORATION
Amphenol Aerospace
40-60 Delaware Avenue
Sidney, New York 13838-1395

PART NO & BIN CODE.	COAXIAL CABLE ACCOMODATED	TYPE ASSEMBLY INSTRUCTIONS	STRIPPING DIMEN- SIONS				TOOLS						
			W	X	Y	X ₁	INNER CONTACT			OUTER CONTACT			
							TOOL SELECTOR SETTING NO.	BASIC CRIMPING TOOL	POSITIONER	BASIC CRIMPING TOOL	POSITIONER	INSERTION TOOL	REMOVAL TOOL
21-33121-541 M39029/28-409 BAND 1 YELLOW 2 BLACK 3 WHITE	M17/095-RG180	II	.312	.140	.190	-	3	M22520/2-01	M22520/2-34 or K323 (Daniels)	M22520/31-01 or GS200 (Daniels)	M22520/31-02 or G2P330 (Daniels)	M81969/8-09 or M81969/14-04	M81969/8-10 or M81969/14-04
	RG-195A/U	III	.312	-	.190	.140*	3						
	RAYCHEM 9528A1318	II	.312	.140	.190	-	4						

* Use this dimension only if crimp sleeve will go over the cable jacket Dia.
and then follow Type II Assembly Instructions.